



CONFIGURATION #1
 Cable **PUSHES** Transmission Arm into REVERSE.
 Use with Shifter Control Positions numbers 2, 4, 5, 7.
 Cable 100-4333-L / 100-6333-L

CONFIGURATION #2
 Cable **PULLS** Transmission Arm into REVERSE.
 Use with Shifter Control Positions numbers 1, 3, 6, 8.
 Cable 100-4333-L / 100-6333-L

CONFIGURATION #3
 Cable **PUSHES** Transmission Arm into REVERSE.
 Use with Shifter Control Positions numbers 2, 4, 5, 7.
 Cable 100-4333-L / 100-6333-L

CONFIGURATION #4
 Cable **PULLS** Transmission Arm into REVERSE.
 Use with Shifter Control Positions numbers 1, 3, 6, 8.
 Cable 100-4333-L / 100-6333-L

CONFIGURATION #5
 Cable **PUSHES** Transmission Arm into REVERSE.
 Use with Shifter Control Positions numbers 2, 4, 5, 7.
 Cable 100-4333-L / 100-6333-L